



3652 Trousdale Drive / Nashville, TN 37204

615-331-8786

Thank you for choosing Smokey Mountain Tops! Below are steps to help prepare for your upcoming project. Please note: A signed quote & 50% deposit are required before template date can be scheduled. We look forward to working with you!

THINGS YOU SHOULD KNOW PRIOR TO TEMPLATING: (Day of Field Measure) The schedule above is an arrival time window & we will do our best to honor the allotted time with you!

- The Customer or Decision Maker of project needs to be On-Site to review items such as overhangs, radius corners, & other questions that are not always clear on drawings.
- Existing countertops should be CLEARED of items which may interfere with the template process.
- All Color and edge selections must be finalized by time of template.
- All Sinks, faucets, cooktops or model #s must be on-site at time of template (in some instances model #s may not work).
- All Farm Sinks & Apron Front Sinks must be installed (in place) PRIOR to time of template.

- Cabinets should be fully installed & leveled including all finished panels before templates can be made. Some Cabinets are installed with finished panels on the ends. Panels should not be added after templates have been made (this will cause tops not to fit properly). Smokey Mountain Tops will check the level of the cabinets with a 6' to 8' level. **PLEASE NOTE: **To avoid return trip charges please confirm that all base cabinets & countertop-related carpentry are completed PRIOR to final field measure; \$125.00 charge will be incurred for return trips to job site. ****

- Upper cabinets must be installed if the job requires full height backsplash.

- It is the customer's responsibility (unless purchased at Smokey Mountain Tops) to make sure that the sink, cooktop and faucets fit into the base cabinet (for example: 42" sinks

will not fit into a 30" sink base). Smokey Mountain Tops will be happy to assist in answering any questions you may have concerning outside purchases.